

INTERNATIONAL LOAD INDEX NUMBERS

GENERAL FARM TIRE INFO

KILOGRAM LOADS AND TRA EQUIVALENT POUND LOADS (NOT APPLICABLE TO PASSENGER CAR OR TRUCK-BUS TIRES)

LI	kg	lbs	LI	kg	lbs	LI	kg	lbs	LI	kg	lbs
50	190	420	90	600	1320	130	1900	4180	170	6000	13200
51	195	430	91	615	1360	131	1950	4300	171	6150	13600
52	200	440	92	630	1390	132	2000	4400	172	6300	13900
53	206	455	93	650	1430	133	2060	4540	173	6500	14300
54	212	465	94	670	1480	134	2120	4680	174	6700	14800
55	218	480	95	690	1520	135	2180	4800	175	6900	15200
56	224	495	96	710	1570	136	2240	4940	176	7100	15700
57	230	505	97	730	1610	137	2300	5080	177	7300	16100
58	236	520	98	750	1650	138	2360	5200	178	7500	16500
59	243	535	99	775	1710	139	2430	5360	179	7750	17100
60	250	550	100	800	1760	140	2500	5520	180	8000	17600
61	257	565	101	825	1820	141	2575	5680	181	8250	18200
62	265	585	102	850	1870	142	2650	5840	182	8500	18700
63	272	600	103	875	1930	143	2725	6000	183	8750	19300
64	280	615	104	900	1980	144	2800	6150	184	9000	19800
65	290	640	105	925	2040	145	2900	6400	185	9250	20400
66	300	660	106	950	2090	146	3000	6600	186	9500	20900
67	307	675	107	975	2150	147	3075	6800	187	9750	21500
68	315	695	108	1000	2200	148	3150	6950	188	10000	22000
69	325	715	109	1030	2270	149	3250	7150	189	10300	22700
70	335	740	110	1060	2340	150	3350	7400	190	10600	23400
71	345	760	111	1090	2400	151	3450	7600	191	10900	24000
72	355	785	112	1120	2470	152	3550	7850	192	11200	24700
73	365	805	113	1150	2540	153	3650	8050	193	11500	25400
74	375	825	114	1180	2600	154	3750	8250	194	11800	26000
75	387	855	115	1215	2680	155	3875	8550	195	12150	26800
76	400	880	116	1250	2760	156	4000	8800	196	12500	27600
77	412	910	117	1285	2830	157	4125	9100	197	12850	28300
78	425	935	118	1320	2910	158	4250	9350	198	13200	29100
79	437	965	119	1360	3000	159	4375	9650	199	13600	30000
80	450	990	120	1400	3080	160	4500	9900	200	14000	30900
81	462	1020	121	1450	3200	161	4625	10200	201	14500	32000
82	475	1050	122	1500	3300	162	4750	10500	202	15000	33100
83	487	1070	123	1550	3420	163	4875	10700	203	15500	34200
84	500	1100	124	1600	3520	164	5000	11000	204	16000	35300
85	515	1140	125	1650	3640	165	5150	11400	205	16500	36400
86	530	1170	126	1700	3740	166	5300	11700	206	17000	37500
87	545	1200	127	1750	3860	167	5450	12000	207	17500	38600
88	560	1230	128	1800	3960	168	5600	12300	208	18000	39700
89	580	1280	129	1850	4080	169	5800	12800	209	18500	40800

- TRACTOR
- HARVEST
- SPRAYER
- IRRIGATION
- FRONTS & IMPLEMENTS
- FORESTRY
- DISCONTINUED
- LOAD & INFLATION TABLES
- GENERAL FARM TIRE INFORMATION
- INDEX